

**Pixsys srl** Via Po, 16 I - 30030 Mellaredo di Pianiga VE Ph. +39 041 519 0518 Fax +39 041 519 0027 www.pixsys.net - sales@pixsys.net

Subject to modifications without prior notice

# Pixsys pressure sensor (Submersible)

### **Safety standards**

Carefully read the instructions and safety measures in this manual before using the device. Disconnect power before performing any interventions on the electrical connections or hardware settings. Only qualified personnel may use/perform maintenance in full respect of the technical data and declared environmental conditions. Do not dispose of electrical appliances together with household waste. In compliance with the European Directive 2002/96/EC, waste electrical equipment must be collected separately for eco-compatible reuse or recycling.


### chnical specifications

Technical specificat		-		
Accuracy	± 0.5% F.S.	Storage temperature	ECL:	– 40°C +8
Operating and media temperature	– 10°C +70°C			


#### **Ordering codes** 2

Item code Des	scription Item code	Description	Item code	Description	Item code	Description
2000.40.149 0	200 mbar 2000.40.15	0 0400 mbar	2000.40.152	0600 mbar	2000.40.147	010 bar
2000.40.160 0	300 mbar 2000.40.15	1 0500 mbar	2000.40.155	01 bar		


### Type label description (example 4...mH20 model) 3



#### **Electrical connections** 4



### 4.1 Pressure connection



## 4.2 Connection of the measuring equipment

