

LDALI-RM8 L-DALI 8-channel Relay Module

Installation instructions

Instructions de montage


Instruzioni di montaggio


Montageanweisung

Instrucciones de montaje

Montagevoorschrift

Monteringsanvisning







SWITCH INDICATES STATUS MANUAL CONTROL (MAINTENANCE)

Connectors		
Optional 24V DC POWER SUPPLY	1	+
	2	-
DALI (2mA)	3	DA
	4	DA
Digital Inputs DI (SHORT INPUT x TO GND TURNS RELAY x ON)	5	Input DI1
	6	Input DI2
	7	Input DI3
	8	Input DI4
	9	Input GND
	10	Input DI5
	11	Input DI6
	12	Input DI7
13	Input DI8	
14	Input GND	


Connectors		
POWER INPUT 85-240 VAC 50 / 60 Hz	15	Input N, neutral line
	16	Input L, phase line
DIGITAL OUTPUT RELAY 16A	17	Relay 1
	18	Relay 1
	19	Relay 2
	20	Relay 2
	21	Relay 3
	22	Relay 3
	23	Relay 4
	24	Relay 4
	25	Relay 5
	26	Relay 5
	27	Relay 6
	28	Relay 6
	29	Relay 7
	30	Relay 7
	31	Relay 8
	32	Relay 8



2 poles: Weidmüller BLZP 5.08/02/180
5 poles: Weidmüller BLZP 5.08/05/180



4.5 lb-in/0.5 Nm




N L 85-240VAC
 PWR 50/60Hz
 1 2 3 4 5 6 7 8
 Relay 1 - 8: 16A 277 VAC
LOYTEC
 www.loytec.com
LDALI-RM8
 24 VDC DALI
 + - DA DA
 Made in Austria
 Digital Inputs
 D11 D12 D13 D14 GND D15 D16 D17 D18 GND

[Optional 24V DC
 power supply]
 +
 -
 DA
 DA

optional: digital input for manual override ON

35 mm x 7.5 mm DIN rail (EN 50022, BS 5584, DIN 46277-3)




installation DIN rail 1.0

Device type

Date Code

Serial number of the device



label 1.1

Document 88088901 Web edition
01/2020
Printed in Austria
Data is subject to change

 **LOYTEC**
A Delta Group Company
<http://www.loytec.com>
support@loytec.com